


**JLWD 1609**

# I 600 spin washer-dryer

# Instruction manual



# John Lewis



# Important safety information

It is most important that this instruction book should be retained with the appliance for future reference. Should the appliance be sold or transferred to another owner, or should you move house and leave the appliance, always ensure that the book is supplied with the appliance in order that the new owner can get to know the functioning of the appliance and the relevant warnings.

These warnings have been provided in the interest of safety. You **MUST** read them carefully before use or installation by a qualified person.

If you are unsure of the meanings of these warnings contact the John Lewis branch from which you purchased the appliance.

## Installation

- This appliance is heavy. Care should be taken when moving it.
- It is dangerous to alter the specifications or attempt to modify this product in any way.
- All packing and transit bolts must be removed before use. Serious damage can occur to the product and to property if this is not adhered to. See relevant section in instructions.
- Care must be taken to ensure that the appliance does not stand on the electrical supply cable.
- If the machine is situated on a carpeted floor, please adjust the feet in order to allow air to circulate freely.
- Only wash and dry fabrics which are designed to be machine washed and dried. If in doubt, consult the care label on the clothes.
- Before washing, ensure that all pockets are empty and buttons and zips are fastened. Avoid washing frayed or torn articles and treat stains such as paint, ink, rust, and grass before washing. Underwired bras must NOT be machine washed.
- Any objects such as coins, safety pins, nails, screws, stones or any other hard, sharp material can cause extensive damage and must not be placed into the machine.
- Garments which have been in contact with volatile petroleum products should not be machine washed. If volatile cleaning fluids are used, care should be taken to ensure that the fluid is removed from the garment before placing in the machine.

## Child Safety

- This appliance is designed to be operated by adults. Children should not be allowed to tamper with the controls or play with the product.
- Pets and children have been known to climb into washer-dryers. Please check your drum before use.
- The glass door becomes very hot during the washing cycle. Keep children away from the vicinity of the appliance whilst it is in operation.
- Keep all packaging well away from children.
- Keep all detergents in a safe place out of children's reach.
- When the appliance is to be scrapped, cut off the electrical supply cable. Disable the door catch in order to prevent children from becoming trapped inside while playing.
- Wash small items such as socks, laces, washable belts etc in a washing bag or pillow case as it is possible for such items to slip down between the tub and the inner drum.
- Only use the advised quantities of fabric softener. Damage to the fabric can ensue if you over-fill. Refer to the manufacturer's recommendations of quantities.
- As some duvets and eiderdowns should be washed/dried in large commercial machines because of their bulk, please check with the manufacturer of the item before washing in a domestic machine.
- The users should always check that they have not left their gas lighters (disposable or otherwise) in their clothing.
- Never tumble dry items that have had contact with chemicals such as dry cleaning fluid. These are of a volatile nature and could cause an explosion. Only tumble dry items which have been washed in water or require airing.

## Use

- Always unplug the appliance and turn off the water supply after use.
- Do not overload the appliance. See relevant section in the instruction book.
- Plastic detergent dispensers should not remain in the drum during the drying cycle, as the plastic used is not designed to withstand the heat. If you wish to wash-through-to-dry you should use the conventional detergent dispenser drawer.

## Maintenance and cleaning


- Leave the porthole door slightly ajar between washes to preserve the door seal.
- For information on maintenance and cleaning your washing machine see page 26 of this instruction manual.

## Service


- This product should only be repaired or serviced by an authorised Service Engineer and only genuine approved spare parts should be used.

## Ecological hints

To save water and energy and help protect the environment, we recommend that you follow these hints:

- Normally soiled laundry may be washed without prewashing in order to save detergent, water and time (the environment is protected too!).
- The machine works more economically if it is fully loaded.
- With adequate pre-treatment, stains and limited soiling can be removed; the laundry can then be washed at a lower temperature.
- Measure out detergent according to the water hardness, the degree of soiling and the quantity of laundry being washed.
- Try to load the maximum drying capacity of the machine as small loads are **uneconomical**.
- Save energy and reduce drying time by ensuring the laundry load has been thoroughly spun before attempting to machine dry.
- Materials marked with the symbol  are recyclable.
- Check with your local Council or Environmental Health Office to see if there are facilities in your area for re-cycling this appliance.
- When the appliance is to be scrapped, cut off the power supply cable and make the door lock device unusable to prevent young children from being trapped inside.
- Help to keep your country tidy - use authorised disposal sites for your old appliance.

## Environmental information

The symbol  on the product or on its packaging indicates that this product may not be treated as household waste. Instead it should be taken to the appropriate collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local council, your household waste disposal service or the shop where you purchased the product.

---

### WARNING:



**A cut off plug inserted into a 13 amp socket is a serious safety (shock) hazard. Ensure that the cut off plug is disposed of safely.**

---

# Contents

## For the User

Important Safety Information	2-3
Description of the Appliance	5
The Control Panel	12-15
Programme information	16
Special features	16
Using your washing machine	17-19
Drying	20
Hints & Tips on Washing and Drying	21
Wash Care Symbols	22
Washing Programmes	23-24
Drying Programmes	25
Maintenance and Cleaning	26
Descaling	26
After each wash	26
Maintenance Wash	26
External cleaning	26
Cleaning the dispenser drawer	26
Cleaning the drawer recess	26
Cleaning the pump	26-27
Cleaning the water inlet filter	27
The dangers of freezing	27
Emergency emptying out	28
Something Not Working	29-30
Repairs - After Sales Service	31
Spare parts	31

## For the Installer

Installation	6
Technical Specifications	6
Unpacking	7
Positioning	7
Installation on a suspended floor	7/8
Plumbing in	8
Water inlet	8
Water drainage	8/9
Levelling	9
In the interest of the environment	10
Electrical connection	11

## Guide to use the Instruction Manual

The following symbols will be found in the text to guide you throughout the instructions:



**Safety instructions**



**Hints and tips**



**Environmental information**




This appliance complies with the following E.E.C. Directives:




- 73/23 EEC of 19.2.73 (Low Voltage Directive) and subsequent modifications;
- 89/336 EEC of 3.5.89 (Electromagnetic Compatibility Directive) and subsequent modifications.


# Description of the appliance

- 1 Detergent dispenser drawer
- 2 Control panel
- 3 Door opening handle
- 4 Drain pump
- 5 Adjustable feet



## Detergent dispenser drawer

-  Prewash
-  Main wash
-  Fabric softener




## Child safety feature





This machine incorporates a special child safety feature to prevent small children from being trapped inside the machine.

To activate this device, rotate the button (without pressing it) inside the door clockwise until the groove is horizontal. If necessary use a coin. This prevents the door being closed.

To disable this device and close the door, rotate the button anti-clockwise until the groove is vertical.



# Installation

-  It is dangerous to alter the specifications or attempt to modify this product in any way.
-  Care must be taken to ensure that the appliance does not stand on the electrical supply cable.
-  Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.
-  Any plumbing work required to install this appliance should be carried out by a qualified plumber or competent person.

## Technical specifications

DIMENSIONS	Height	85 cm
	Width	60 cm
	Depth	63 cm
POWER SUPPLY VOLTAGE		230-240 V/50 Hz
TOTAL POWER ABSORBED		2050 W (10 A)
WATER PRESSURE	Minimum	0.05 MPa (0.5 bar)
	Maximum	0.8 MPa (8 bar)
MAXIMUM RECOMMENDED LOAD	<b>Washing</b>	
	Cotton, linen	7 kg
	Synthetics	3.5 kg
	Delicate fabrics	3.5 kg
	Wool/Hand wash	2 kg
	<b>Drying</b>	
	Cotton, linen	3.5 kg
	Cotton Big capacity	4 Kg
	Synthetics	2 kg
SPIN SPEED	Maximum	1600 rpm
CONSUMPTION DATA FOR WASHING 7 KG NORMALLY SOILED COTTON ITEMS WITH PROGRAMME ” “Cottons Economy 60”:	Energy	1.19 kWh
	Water	45 litres

## Unpacking





All transit bolts and packing must be removed before using the appliance.

Keep all packaging away from children.

You are advised to keep all the transit bolts for re-use in case the machine is to be transported again.



After removing all the packaging, with assistance carefully lay machine on it's back to remove the polystyrene base from the bottom.

Remove the power supply cable and the draining hose from the hose holders on the rear of the appliance.





With the spanner provided unscrew and remove the central rear bolt **A**.

Unscrew and remove the two large rear bolts **B** and the six smaller bolts **C**.





Remove the bracket **D**, refit the six smaller bolts **C** and slide out the relevant plastic spacer **E**.



Open the porthole and remove the polystyrene block fitted on the door seal.

Fill the smaller upper hole and the two large ones with

the corresponding plastic plug caps supplied in the bag containing the instruction booklet.



Connect the water inlet hose as described under the paragraph "Water inlet".

### Important !

You are advised to keep all the packaging for re-use in case the machine is to be transported again. In case of moving out the same precautions as per paragraph "The dangers of freezing" must be taken i.e. the residual water in the hoses must be pumped out.

## Positioning

Install the machine on a flat hard floor.

Make sure that air circulation around the machine is not impeded by carpets, rugs etc. Check that the machine does not touch the wall or other kitchen units.

Never place cardboard, wood or similar materials under the machine to compensate for any unevenness in the floor.

If the floor is carpeted or covered with crumbly or soft material, insert a rigid support base under the feet to prevent noise, vibration or displacement. The base should protrude a few centimetres beyond the edges of the machine.



### Warning

The machine should NOT be placed on deep pile carpeting.

## Installation on a suspended floor

Suspended wooden floors are particularly susceptible to vibration. To help prevent vibration we recommend you place a waterproof wood panel, at least 15 mm thick under the appliance, secured to at least 2 floor

boards with screws. If possible install the appliance in one of the corners of the room, where the floor is more stable.

### Note

Please ensure that when the appliance is installed it is easily accessible for the engineer in the event of a breakdown.

## Plumbing In

Your new machine has been designed to be permanently plumbed in to your home's water supply and drainage system. However, if this is not possible, it may be connected to a suitable existing tap with the drain hose discharging into a sink.


The appliance has an inlet hose, with female 3/4" BSP thread connector. If this connection is not compatible with the plumbing of the existing installation, a variety of connectors are available from good hardware stores and plumbers merchants to suit most domestic plumbing. Any alteration to your existing plumbing must be carried out by a competent person, or qualified plumber.

## Water inlet

An inlet hose is supplied and can be found inside the machine drum.

**Do not use the hose from your previous machine to connect to the water supply.**

1. Open the porthole and extract the inlet hose .
2. Connect the hose with the angled connection to the machine.




3. Remove the security gasket cup by turning and pulling it away. Pay attention not to move or remove the gasket.

### Important!

**Do not place the inlet hose downwards. Angle the hose to the left or right depending on the position of your water tap.**

4. Set the hose correctly by loosening the ring nut. After positioning the inlet hose, be sure to tighten the ring nut again to prevent leaks.

5. Connect the hose to a tap with a 3/4" thread. Always use the hose supplied with the appliance.



The inlet hose is provided with a water stop device, which protects against damage caused by water leaks in the hose which could develop due to natural ageing of the hose. This fault is shown by a red sector in the window "A". Should this occur, turn the water tap off and refer to your Service Centre to replace the hose. Installation should comply with local water authority and building regulations' requirements.

**The appliance must be connected to a cold water supply.**

A minimum water pressure of 0.05 MPa (0.5 bar) is required for safe operation of the appliance.

If you cannot make the cold water connection direct from the rising mains, you may be able to operate the appliance from your cold water storage system.

There should be a minimum vertical distance of 5.02m (16.5 ft) between the appliance's inlet and the bottom of the water storage tank.

## Water drainage

This appliance is designed to be permanently plumbed into your home's drainage system using one of the following methods.


### 1. Into a drainage standpipe.

Firstly form a hook in the end of the drain hose using the "U" piece supplied.




Place the drain hose into your standpipe, which should have an internal diameter of approximately 38mm thus ensuring there is an air break between the drain hose and standpipe.






When discharging into a standpipe ensure that the top of the standpipe is no more than 90cm (35.4") and no less than 60cm (23.6") above floor level.




The drain hose may be extended to a maximum of 4 metres. An additional drain hose and joining piece is available from your local Service Force Centre. The joining piece must have an internal diameter of 18 mm.

If your drain hose looks like this (see below) you do not require the "U" piece". Just push the hose firmly into the standpipe.




## 2. Onto a sink outlet spigot.

If the outlet spigot has not been used before, remove any blanking plug that may be in place.



Push the drain hose onto the spigot and secure with a clip, ensure a loop is formed in the drain hose (see diagram) to prevent waste from the sink entering the washing machine.




## Important

Before connecting the machine to new pipework or to pipework that has not been used for some time, run off a reasonable amount of water to flush out any debris that may have collected in the pipes.

## Levelling

Level the machine by raising or lowering the feet. The feet may be tight to adjust as they incorporate a self locking nut, but the machine **MUST** be level and stable.

If necessary, check the setting with a spirit level.




Any necessary adjustment can be made with a spanner. Accurate levelling prevents vibration, (see note on positioning), noise and displacement of the machine during operation.

Some vibration is inevitable, especially if mounted on a wooden floor.

Sprung wooden floors are particularly susceptible to vibration. For advice, consult a builder. If possible, always place the machine on a solid floor.

## In the interest of the environment

Washer-dryers should be connected to the FOUL drainage system, the water will then be taken to a sewage works for treatment before being discharged safely into a river.



It is essential that these appliances are not connected to the surface water drainage system as this water is discharged directly into a river or stream and may cause pollution.

If you require any further advice please contact your local water authority.

# Electrical connection


Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.



## **WARNING: THIS APPLIANCE MUST BE EARTHED.**

**Should the appliance power supply cable need to be replaced, this MUST be carried out by a Service Force agent. The manufacturer declines any liability should this safety measure not be observed.**

Before switching on, make sure the electricity supply voltage is the same as that indicated on the appliance's rating plate. The rating plate is located at the bottom of the rim of the open door.




The appliance is supplied with a 13amp plug fitted. In the event of having to change the fuse in the plug supplied, a 13amp ASTA approved (BS1363/A) fuse must be used.

Should the plug need to be replaced for any reason, proceed as described below.

The wires in the mains lead are coloured in accordance with the following code:

Green and Yellow	- Earth
Blue	- Neutral
Brown	- Live



The wire coloured green and yellow must be connected to the terminal marked with the letter «E» or by the earth symbol  $\equiv$  or coloured green and yellow.

The wire coloured blue must be connected to the terminal marked «N» or coloured black.

The wire coloured brown must be connected to the terminal marked «L» or coloured red.

Upon completion there must be no cut, or stray strands of wire present and the cord clamp must be secure over the outer sheath.

## **WARNING:**



**A cut off plug inserted into a 13 amp socket is a serious safety (shock) hazard. Ensure that the cut off plug is disposed of safely.**



**The plug must still be accessible after the appliance has been installed**



**The appliance should not be connected to the electrical supply by means of an extension cable.**

The power supply cable must be easily accessible after installing the appliance.

## **Important**


If the mains supply cable is damaged it must be replaced; contact our warranty administrators on 0870 0107887 who will give you details for your local Service Force Centre.

## **Permanent connection**

In the case of permanent connection it is necessary that you install a double pole switch between the appliance and the electricity supply (mains), with a minimum gap of 3mm between the switch contacts and of a type suitable for the required load in compliance with the current electrical regulations.

The switch must not break the yellow and green earth cable at any point.

# The control panel




## 1 Detergent dispenser drawer

## 2 Programme selector dial

The programme selector dial is divided into the following sections:

- Cottons,
- Synthetics,
- Delicates
- Wool (Hand washing)
- Special programmes from “Rinses” to “14 Minute wash”
- Reset programme/Switching the machine Off «Off»



The selector dial can be turned either clockwise or anticlockwise to select the required wash and drying programme .

Positions “**Economy**” correspond to an ENERGY SAVING programme.

Before setting the dial to any position ensure that the machine is switched off.

### Important!

**At the end of the programme the selector dial must be turned to position “Off”.**

## 3 “Spin” button

Press this button repeatedly to change the spin speed, if you want your laundry to be spun at a speed different from the one proposed by the washer-dryer or to select position “Rinse hold”. The relevant light will light up.

### Spin speed

The following speeds are available for the different fabrics:

- Cottons: max 1600 r.p.m. /1200/800/500
- «45 Minute wash»: max 1200 r.p.m /800/500
- Synthetics, Wool and «14 Minute wash»: max 800 r.p.m. /500
- Delicates: 500 r.p.m.

### Position “Rinse hold”

If you select this option, the last rinse water is not emptied out, to prevent the fabrics from creasing. When the programme has finished, the light of the **Start/Pause** button goes out, the **Door lock** light is alight and the door is locked to indicate that the water must be emptied out.

To empty out water there are 2 possibilities:

- Select programme “**Drain**”:  
The water is emptied out without spinning.
- Select programme “**Spin**”: This automatically defaults to the setting for cotton items which can be reduced by pressing the relevant button.  
The water is emptied out and the laundry is spun at the selected spin speed.

**Attention!** Before selecting programmes **Drain** or **Spin**, the selector dial has to be positioned on “Off” position (reset).

The **Rinse Hold** option CANNOT be selected for the automatic Washing & Drying programme.

## 4 “Automatic Dry” button

This button allows you to choose the required degree of drying for cottons and synthetics:

- Extra dry (only for cottons)
- Cupboard dry (cottons and synthetics)
- Iron dry (only for cottons)

The drying time is automatically adjusted by the machine: the laundry will be dried to the selected degree of dryness.

## 5 “Time dry” button

If you wish to carry out a timed programme instead of an electronic programme push this button until the drying time you want appears in the display according to the fabrics (cotton or synthetics) you have to dry.

For **Cottons** you can select a drying time from 10 minutes to 200 minutes .

For **Synthetics** you can select a drying time from 10 minutes to 130 minutes.

## Options

Depending on the programme, different functions can be combined. These must be selected after choosing the desired programme and before pressing the “**Start/Pause**” button.

When these buttons are pressed, the corresponding pilot lights illuminate. When they are pressed again, the pilot lights go out.

If an incorrect option is selected, the red pilot light of the **Start/Pause** button flashes for a few seconds and the message **Err** is displayed.

## 6 “Prewash” button

Select this option if you wish your laundry to be prewashed at 30°C max. before the main wash (**not available for Wool, “45 Minute wash” and “14 Minute wash”**).

The prewash cycle ends with a short spin at 650 rpm in programmes for cotton and synthetic fabrics, whereas in the programme for delicate fabrics the water is only drained. This option can be selected for heavily soiled laundry.

## 7 “Extra rinse” button

This option can be selected with all programmes, except Wool and “**14 Minute wash**”. The machine adds 2 rinses for cotton and 1 rinse for synthetics and delicates.

This option is recommended for people who are allergic to detergents, and areas where the water is very soft.

## 8 “Start/Pause” button

This button has two functions:

- **Start:** after you have selected the desired programme and options, press this button to start the washer-dryer. The green light of the button will stop flashing and remain lit.  
If you have selected a delay time, the countdown will begin and will be shown on the display.
- **Pause:** when you press this button again, the programme in progress is interrupted. The light of the button will start flashing. To restart the programme from the point at which it was interrupted, **press the button again**.

### Important!

You must set the washer-dryer to Pause before you make any change in the programme in progress.

## 9 Door lock light

After you have started the programme, the Door lock light illuminates to indicate that the machine starts working and the door is locked.

This light is also on during the countdown of the delay start.

This light indicates if the door can be opened:

- **light on:** the door cannot be opened.  
The appliance is operating or there is water left in the tub. **Attention!** If the door is locked do not try to open or force it!
- **light off:** the door can be opened.  
The washing programme has finished.

## 10 “Delay start” button

This button enables you to delay the starting of the programme for 30 min - 60 min - 90 min, 2 hours and then by 1 hour increments up to a maximum of 20 hours. The delay you have selected is shown on the display for about a few seconds; afterwards, the duration of the programme reappears.

You must select this option **after** you have set the programme and **before** you press the “**Start/Pause**” button.

The time value shown on the display will decrease by one unit every hour.

**You can change the delay time at any moment**, before you press the “Start/Pause” button.

If you have already pressed the “Start/Pause” button, and you wish to **cancel** the delay time, proceed as follows:

- Set the machine to PAUSE by pressing the “Start/Pause” button;
- Press the “Delay start” button until the symbol “0” is displayed.
- Press the “Start/Pause” button again.

### Important!

The “Delay start” **cannot** be used with “Drain” programme.

### Note!


The door will be locked throughout the delay time.

If you need to open the door, you must first set the washer-dryer to Pause by pressing the “**Start/Pause**” button. After you have closed the door, press the “**Start/Pause**” button again.

## II Display (Programme time)

The following pieces of information are shown on the display:

- **Duration of washing programme** in hours and minutes, after you have selected a programme (for example 2.05).




The duration is calculated automatically on the basis of the maximum recommended load for each type of fabric.

While the programme is running, the displayed time value decreases by one unit every minute.



- **The washer-dryer has stopped with water in the tub**, if the “Rinse hold” option has been selected: this is indicated by a **flashing zero**. The **Door lock** light is still on and the door is still locked.
- **The washer-dryer has completed the programme**: this is indicated by a **flashing zero**. The **Door lock** light has gone off. It is now possible to open the door.




After starting the programme, the remaining time is updated every minute.

### Stand-by

If your laundry is not removed within 10 minutes after the programme has finished, the backlight of the display switches off and the energy saving system will be enabled. Only the pilot light of the **Start Pause** button is blinking to indicate that the appliance has to be switched off.

By pressing any button the appliance will come out from the energy saving status and you could set another washing programme or switch off the appliance.

- **Selection of drying time** in minutes .




After starting the programme, the remaining time is updated every minute.

**Important!**


If you select a drying time longer than 55 minutes, after a few seconds, the display will show it in hours and minutes.

- **Delay start**, a time value indicated in hours (20 hours max) and selected by means of the relevant button.




The delay time is displayed for a few seconds, then the duration of the selected programme reappears. After you have pressed the Start/Pause button, the countdown is updated every hour, and, for the last hour, every minute.

- **An incorrect option selection has been made:** this is indicated by the message **Err** when a function incompatible with the current programme is selected.



- **An alarm code** indicates a fault in the machine operation (see page 29, "Something Not Working")



# Programme information

## Easy iron 40°

This programme at 40°C reduces creasing on synthetic garments and therefore reduces the amount of ironing required. The laundry is gently washed and spun to prevent the fabrics creasing.

## Rinses

With this programme it is possible to rinse and spin garments which have been washed by hand. The machine performs 3 rinses, followed by a final long spin at the maximum speed.

## Important!

The spin speed will automatically default to the setting for cotton items. If required, reduce the speed to the desired level by pressing the relevant button for other fabric types.

## Drain

For emptying out the water with the “Rinse hold” option, if you want to change a programme due to a wrong selection and it is necessary to empty out the water.

Firstly, turn the programme selector dial to **Off**, then select the **Drain** programme and press the **Start/Pause** button.

## Spin

Separate long spin at the max speed for hand washed garments. It automatically defaults to the setting for cotton items. You can reduce the speed by pressing the relevant button to adapt it to the fabrics to be spun.

## 45 Minute wash

This is a complete programme to be used for half load of slightly or normally soiled cotton items. This programme performs a good washing efficiency in a short time.

## 14 Minute wash

Suitable for laundry which is very lightly soiled or which needs freshening up.

## Off = Reset / Switching the machine off

To reset a programme or switch the machine off, turn the selector dial to **Off**.

A new programme can now be selected.


# Special features

## Child lock


The ‘Child Lock’ feature will allow you to lock the controls while the machine is running to prevent tampering.

You can activate this device:

- Before starting the machine
- When the programme is running

Activate «Child Lock» by pressing the **Spin** and **Automatic dry** buttons simultaneously for 5 seconds until the padlock symbol  is displayed on the screen.

To de-active «Child Lock» simply press the **Spin** and **Automatic dry** buttons simultaneously until the

padlock symbol  on the screen disappears. «Child Lock» will remain activated until you deactivate it, even if the machine is turned off.

## Buzzer

This appliance incorporates a buzzer, which sounds at the end of the cycle and if there is a fault.

To deactivate the acoustic signal (only at the end of cycle), press simultaneously for a few seconds the buttons **Time dry** and **Prewash**.

By pressing these 2 buttons again the acoustic signal is reactivated. .



# Using the washing machine

Before the first wash, we recommend that you run a cotton cycle at 90°C or 95°C, without any laundry in the machine, to remove any manufacturing residue from the drum and tub.

Pour 1/2 a measure of detergent into the dispenser drawer and start the machine.


## WASHING

### 1. Load the laundry


Open the door.


Place the laundry in the drum, one item at a time, shaking them out as much as possible.

Close the door.





### 2. Measure out the detergent

Pull out the dispenser drawer until it stops. Measure out the amount of detergent required and pour it into the main wash compartment .

If you wish to carry out the prewash, pour detergent into the appropriate compartment marked .

### 3. Measure out the fabric softener


If required, pour fabric softener into the compartment marked , **without exceeding the «MAX» mark.**



Close the drawer gently.

### 4. Switch the machine on

Turn the selector dial to the the desired position to switch the machine on. To switch the appliance off turn it to **Off**.



### 5. Select the desired programme/temperature

The display will show the duration of the selected programme, calculated on the basis of the maximum load for each type of fabric. The **Start/Pause** button light will start flashing.


If the load of laundry to be washed is small, at the beginning of the cycle the display will still indicate the duration relevant to the maximum load. The duration value will be gradually adjusted during the cycle.



### 6. Select the spin speed or the Rinse hold option

Press the “**Spin**” button repeatedly in order to select the desired spin speed or the **Rinse hold** option. If you select this option, the last rinse water is not emptied out.

The relevant light will light up.




## 7. Select the desired options

If your laundry is very dirty, it may be advisable to select the “**Prewash**” option.


If you wish the laundry to undergo an extra rinse, select the “**Extra Rinse**” option.

The relevant light illuminates.



## 8. Select the “Delay start”

**Before you start the programme**, if you wish to delay the start, press the **Delay start** button repeatedly, or keep it pressed, to select the desired delay. The selected delay time value (up to 20 hours) will appear on the display for a few seconds, then the duration of the programme will appear again.



During this period it is possible to load other laundry: press the “**Start/Pause**” button. Open the door. Load the laundry. Close the door and press the “**Start/Pause**” button again.

## 9. Start the programme

Press the “**Start/Pause**” button. The relevant light will stop flashing, and only the light relevant to the phase that is in progress will remain lit. The machine starts operating.

If you have chosen a delayed start, the washer dryer will begin the countdown.

The display will show the duration of the programme or the selected delay.

## 10. How to change an option or a programme during its cycle

It is possible to change some options before the programme carries them out.

Before you make any change, you must pause the machine by pressing the **Start/Pause** button.

Changing a running programme is possible only by **resetting it**.

Turn the programme selector dial to **Off** and then to the new programme position.

Start the new programme by pressing the **Start/Pause** button. The washing water in the tub will not be emptied out.

## 11. How to interrupt a programme

Press the **Start/Pause** button to interrupt a programme which is running, the corresponding light starts to flash. Press the button again to restart the programme.

## 12. How to open the door during the cycle of a programme

You can open the door, after having set the washing machine to Pause, provided the following conditions exist:

- The machine is not in the heating phase beyond 55°C;
- The level of the water is not high;

If these requirements are met, when you pause the washer dryer, the **Door lock** light goes off and the door can be opened.

Should it not be possible to open the door, and should it be absolutely necessary to do so, switch the machine off by turning the selector dial to **Off**.

After some minutes, you can open the door.

**Pay attention to the level and temperature of the water in the machine!**

When you close the door to restart the programme turn the dial to the previous programme repeating the options previously selected and press **Start/Pause** button.

### 13. End of programme

At the end of the programme, the machine stops automatically and displays a flashing zero.

The **Start/Pause** button light and the **Door lock** light go out.

Turn the programme selector dial to **Off** to switch the machine off.

Remove the laundry from the washer dryer.

Check whether the drum is completely empty, by rotating it with your hand. This is to prevent any items of laundry accidentally remaining in the drum.

We advise that you close the water supply tap and disconnect the plug from the socket.

If you do not intend to carry out another wash, close the water tap. Leave the door open to prevent the formation of unpleasant smells.

# Drying


## DRYING ONLY

The recommended load to dry in your washer-dryer is 3.5 kg for cotton and 2 kg for synthetics.


**Note! Only with the timed drying, it is possible also to dry up to 4 kg of cotton items (see the drying programmes).**

The water tap must be open and the drain hose must be positioned in the sink or connected to the drain pipe.

1. Load the laundry.
2. Turn the programme selector dial to the «Drying» programme in the **Cottons** or **Synthetics** section.
3. If you wish to carry out the electronic drying, press **Automatic dry** button until the light of the desired dryness degree illuminates.



If you want a timed drying, press the “**Time dry**” button until the time you want appears on the display (see page 14).



4. Press the **Start/Pause** button to start the programme.
5. At the end of the programme, the buzzer sounds. A flashing zero «0» will appear on the display. At this point, begins an «anti-crease phase», which lasts about 10 minutes. The door can be opened only at the end of this phase.

### Attention!

If you wish to open the door before the anti-crease phase or to interrupt it, press any key or turn the programme selector dial to any programme position (except **Off**), the door can be immediately opened.

6. Turn the programme selector dial to **Off** to switch the machine off and remove the laundry.

### Note:

The programme time will automatically increase by up to 2 minutes, this is quite normal.

## AUTODRYING

For NON-STOP programmes, the recommended load size to wash and dry is 3,5 kg for cotton and 2 kg for synthetics.

**Note! Only with the timed drying, it is possible also to dry up to 4 kg of cotton items (see the drying programmes).**

Do not use a dosing device/ball when carrying out a washing & drying programme.

1. Load the laundry.
2. Add detergent and fabric softener.
3. Switch the machine on by turning the selector dial to the wash programme/fabric and temperature in the **Cotton** or **Synthetics** section.
4. Select the drying time or dryness degree.
5. Select the required options by pressing the relevant buttons. If possible, do not select a spin speed lower than that proposed by the appliance to avoid too long a drying time therefore saving energy. The reduction of the spin speed is only possible after selecting drying. The lowest values you can select is 1200 r.p.m. for Cottons and 800 r.p.m. for Synthetics with Timed Drying.
6. Start the programme by pressing the **Start/Pause** button.
7. At the end of the programme, the buzzer sounds. A flashing zero «0» appears on the display. At this point of the programme, starts an anti-crease phase which lasts about 10 minutes. During this time the door is locked and the display keeps showing the flashing zero.  
(If you wish to open the door before or during the anti-crease phase, please follow the instructions given in the previous chapter).
9. Turn the programme selector dial to **Off** to switch the machine off and remove the laundry.

# Hints & tips on washing and drying

Do **NOT** overload the machine. Weigh the laundry the first few times you use the appliance.


The average weights of the most common items are listed below as a guide:

**1 000g = 1 kg**

Sheet	700-1000 g
Pillow case	100-200 g
Tablecloth	400-500 g
Serviette	50-100 g
Tea towel	70-120 g
Linen hand towel	100-150 g
Towelling hand towel	150-250 g
Towelling bath towel	700-1000 g
Bath robe	1000-1500 g
Man's shirt	200-300 g
Apron	150-200 g


- Load the laundry loosely alternating large items with small ones.
- Sort the laundry according to the type of fabric, colour-fastness and how dirty it is.
- Avoid washing unhemmed or torn items as they may unravel.
- Before washing, empty all pockets of small objects which may have been left inside (coins, keys, screws etc). as these could damage the drain pump.
- When washing curtains, remove the hooks.
- Close poppers and zips and fasten loose buttons.
- It is essential to wash new coloured items separately when washing for the first time.
- When washing fabrics requiring different wash temperatures together, always select the lowest temperature.
- White items should not be washed with coloured items.
- Very small items (handkerchiefs, ribbons, socks etc) should be washed in a washing bag or a pillow case.
- Use a good quality detergent suitable for automatic washing machines.
- Use the correct quantities of detergent.
- For wool, use gentle detergent only in small quantities.
- Bleach is very corrosive; it should be used with care and kept out of reach of children.

- Some stains such as fruit, wine, grass, rust etc. are difficult to remove and should be treated before washing with specific products, which can be found in most household shops. In some cases it may help to soak the stain before washing with a special pre-soak product or biological detergent.
- If you have used the machine to wash, rinse or spin only non-colour fast garments, there may be dye left in the sump. To ensure any subsequent wash is not contaminated with the dye, select and carry out a rinse and spin programme, without any garments, to ensure that any dye is removed from the sump.
- Do not leave the damp laundry load in a heap too long before drying.
- Avoid drying dark clothes with light coloured fluffy items such as towels as these can attract the fluff.
- If you overdry the laundry, besides wasting energy, any subsequent ironing may become more difficult because the fabric could be heavily crumpled.
- Remove the laundry when the appliance has finished drying.
- To avoid a static charge when drying is completed, use either a fabric softener when you are washing the laundry or a fabric conditioner specifically for tumble dryers.
- Particularly delicate items such as synthetic curtains, woollen and silk, garments with metal inserts, nylon stockings, bulky garments such as anoraks, bedcovers, quilts, sleeping bags and duvets must not be machine dried.
- Garments padded with foam-rubber or materials similar to foam-rubber must not be machine dried; they represent a fire hazard.
- Also, fabrics containing residues of setting lotions or hair sprays, nail solvents or similar solutions must not be machine dried in order to avoid the formation of harmful vapours.
- For drying, follow the indications given on the manufacturer's labels.

 May be tumble dried

 Drying at high temperature

 Drying at reduced temperature

 Do not tumble dry

















## **Important:**

As a dryer, the machine works on the condensation principle.

**Therefore, the water tap must be open and the drain hose must drain water into a sink or into the drain pipe, even during the drying cycle.**

# Wash care symbols

Wash care labels inside garments recommend how to launder your clothes with the best results. The care labelling code is in line with care labelling used in the rest of Europe. The symbols used make it easy to select the correct programme on your washer-dryer.

WASHING SYMBOL	WASH ACTION	FABRIC
	Normal (Maximum)	White Cotton or Linen without Special Finishes
	Normal (Maximum)	Cotton, Linen or Viscose without Special Finishes Colourfast at 60°C.
	Reduced (Medium)	Nylon, Polyester/Cotton, Viscose with Special Finishes, Cotton/Acrylic Mix.
	Normal (Maximum)	Cotton, Linen or Viscose Colourfast at 40°C but not 60°C.
	Reduced (Medium)	Acrylics, Acetate, Triacetate, Wool mixes, Polyester/wool blends.
	Much Reduced (Minimum)	Wool, wool mixtures, Silks
	Hand wash only	Do not machine wash
BLEACHING		
	Chlorine bleach may be used	
IRONING		
	Hot iron	Cotton, Linen, Viscose
	Warm iron	Polyester mixtures, Wool
	Cool iron	Acrylic, Nylon, Polyester
DRY CLEANING		
	May be dry cleaned. Other letters and/or a bar beneath the circle will indicate the required process to the dry cleaner.	
TUMBLE DRYING		
	with high heat setting	
	with low heat setting	
	May be tumble dried	
	A cross through any symbol means «DO NOT»	



## Important notes

For best results, always use the dispenser drawer for dispensing detergents and liquid additives. Once the dispenser has been filled, close it by pushing it in gently. This is particularly important if you are using

fabric conditioner to avoid the conditioner entering the machine prematurely.

When using liquid detergent and a prewash programme, place the main wash detergent into the corresponding compartment of the dispenser drawer, after the prewash has finished.

# Washing programmes

Fabrics	Programme/ temperature	Type of laundry	Available options	Load	Consumptions*	
					Energy kWh	Water litres
White cotton	<b>95° Cottons</b>	Sheets, household linen, towels, tablecloths	<b>Spin red./ Rinse hold Prewash Extra rinse</b>	7 Kg	2.1	62
White cotton	<b>Economy 60° Cottons</b>	Sheets, household linen, towels, tablecloths	<b>Spin red./ Rinse hold Prewash Extra rinse</b>	7 Kg	1.19	45
White and coloured cotton	<b>60° 40° - 30° Cottons</b>	Fast coloured and non-fast items, e.g. hand towels, sheets, underwear, tablecloths, shirts, blouses	<b>Spin red./ Rinse hold Prewash Extra rinse</b>	7 Kg	1.35	58
Coloured cotton	<b>Economy 40° Cottons</b>	Coloured items, for example underwear, shirts, blouses	<b>Spin red./ Rinse hold Prewash Extra rinse</b>	7 Kg	1.3	56
Synthetics	<b>60° - 40°- Synthetics</b>	Shirts, blouses, underwear, mixed fabrics	<b>Spin red./ Rinse hold Prewash Extra rinse</b>	3.5 Kg	09	54
Synthetics	<b>Easy iron 40° Synthetics</b>	Shirts, blouses, underwear, mixed fabrics	<b>Spin red./ Rinse hold Prewash Extra rinse</b>	1.5 Kg	0.45	63
Delicates	<b>40° - 30° Delicates</b>	Acrylic, viscose, polyester items, duvets, curtains	<b>Rinse hold Prewash Extra rinse</b>	3.5 Kg	0.55	63
 <b>Wool</b> 	<b>40° - 30° Wool</b>	Garments bearing the "Pure new wool, non-shrink, machine washable" or "Hand wash" label	<b>Spin red./ Rinse hold</b>	2 kg	0.4	58

The "**Cottons Economy 60°**" (White cotton) is the reference programme for the data entered in the energy label, in compliance with EEC 92/75 standards.

\* This data is given purely as an indication: the consumption values may vary in relation to the quantity and type of laundry, the temperature of the water supply and the ambient temperature. The data refers to the highest temperature provided for each programme.

**For the duration of the programmes, please refer to the display on the control panel.**

# Washing programmes

Programme	Programme description	Available options	Load	Consumptions*	
				Energy kWh	Water litres
<b>Rinses</b>	3 rinses Long spin at the max speed	<b>Spin red./ Rinse hold Extra rinse</b>	7 Kg	0.1	46
<b>Drain</b> For emptying out the water	Water draining	-	7 Kg	-	-
<b>Spin</b>	Drain and long spin at max. speed	<b>Spin reduction</b>	7 Kg	-	-
<b>45 Minute wash</b> Short cycle for lightly soiled fabrics	Wash at 60°C 2 rinses Short spin at 1200 rpm	<b>Spin red./ Rinse hold Extra rinse</b>	3.5 Kg	0.9	41
<b>14 Minute wash</b> Ideal for laundry which needs only freshening up	Wash at 30°C 2 rinses Short spin at 800 rpm	<b>Spin red./ Rinse hold</b>	1 Kg	0.18	42
<b>Off (Reset)</b>	For cancelling the programme which is running or to switch the machine off		-	-	-



# Drying programmes

## Automatic drying

Dryness degree	Type of fabric	Max. load
Extra dry	Cotton and linen (bathrobes, bath towels, etc.)	3.5 kg
Cupboard dry	Cotton and linen (towels, T-shirts, bathrobes)	3.5 kg
	Synthetics and mixed fabrics (jumpers, blouses, underwears)	2 kg
Iron dry	Cotton and linen (sheets, tablecloths, shirts, etc.)	3.5 kg

## Timed drying

Degree of drying	Type of fabric	Max. load	Spin speed	Suggested drying time in mins
<b>Suitable for items to put away without ironing</b>	Cotton and linen (towels, T-shirts, bathrobes)	4 kg	1600	125 - 140
			1200	135 - 150
		1.5 kg	1600	35 - 45
			1200	45 - 55
	Synthetics and mixed fabrics (jumpers, blouses, underwear, household linen)	2 kg	800	70 - 80
		1 kg	800	35 - 40
<b>Suitable for ironing</b>	Cotton and linen (sheets, tablecloths, shirts, etc.)	4 kg	1600	105 - 120
			1200	115 - 130
		1.5 kg	1600	30 - 40
			1200	40 - 50

In compliance with EC directive EN 50229 the cotton reference programme for the data entered in the Energy Label must be tested dividing the maximum washing load by two equal parts and drying with TIMED DRYING each of them.

# Maintenance and cleaning

**You must DISCONNECT the appliance from the electricity supply, before you can carry out any cleaning or maintenance work.**

## Descaling

The water we use normally contains lime. It is a good idea to periodically use a water softening powder in the machine. Do this separately from any washing, and according to the softening powder manufacturer's instructions. This will help to prevent the formation of lime deposits.

## After each wash

Leave the door open for a while. This helps to prevent mould and stagnant smells forming inside the appliance. Keeping the door open after a wash will also help to preserve the door seal.

## Maintenance wash

With the use of low temperature washes it is possible to get a build up of residues inside the drum. We recommend that a maintenance wash be performed on a regular basis.

### To run a maintenance wash:

- The drum should be empty of laundry.
- Select the hottest cotton wash programme.
- Use a normal measure of detergent, must be a powder (such as Ariel Futur).

## External cleaning


Clean the exterior cabinet of the appliance with soap and water only, and then dry thoroughly.

## Cleaning the dispenser drawer

The detergent dispenser drawer should be cleaned regularly.


Remove the drawer by pressing the catch downwards and by pulling it out. Flush it out under a tap, to remove any traces of accumulated powder.

To aid cleaning, the top part of the fabric softener compartment should be removed.



## Cleaning the drawer recess

Having removed the drawer, use a small brush to clean the recess, ensuring that all washing powder residue is removed from the upper and lower part of the recess. Replace the drawer and run the rinse programme without any clothes in the drum.



## Cleaning the pump


### The water drain filter

The pump should be inspected if


- The machine does not empty and/or spin
- The machine makes an unusual noise during draining due to objects such as safety pins, coins etc. blocking the pump.

Proceed as follows:


- Disconnect the appliance.
- If necessary wait until the water has cooled down.
- Open the pump door levering on the groove with a coin.
- Place a bowl with a small edge close to the pump to collect any spillage.




- Pull out the emergency emptying cap from the filter cover, using a pliers.
- When no more water comes out, unscrew the pump cover, using a pliers, and remove the filter. Always keep a rag nearby to dry up spillage of water when removing the cover.




- Remove any objects from the pump impeller by rotating it.



- Replace the emergency emptying cap into the filter cover and fix it firmly.



- Close the pump door.




## ⚠ Warning

When the appliance is in use and depending on the programme selected there can be hot water in the pump. Never remove the pump cover during a wash cycle, always wait until the appliance has finished the cycle, and is empty. When replacing the cover, ensure it is securely retightened so as to stop leaks and young children being able to remove it.

## Cleaning the water inlet filter

If your water is very hard or contains traces of lime deposit, the water inlet filter may become clogged. It is therefore a good idea to clean it from time to time. Turn off the water tap. Unscrew the water inlet hose. Clean the filter using a hard bristle brush. Refit the inlet hose. Clean carefully under a fast running tap.



## The dangers of freezing

If the machine is exposed to temperatures below 0°C, certain precautions should be taken.

- Turn off the water tap.
- Unscrew the inlet hose.
- Place a bowl with a small edge close to the pump to collect any spillage from the emergency emptying cap.  
Place the end of the inlet hose in a bowl placed on the floor and let water drain out.
- Screw the water inlet hose back on and reposition the emergency emptying cap on again into the filter cover.
- When you intend to start the machine up again, make sure that the room temperature is above 0°C.

## Emergency emptying out

If the water is not discharged, proceed as follows to empty out the machine:

- Pull out the plug from the power socket;
- Close the water tap;
- If necessary, wait until the water has cooled down;
- Open the pump door using a suitable tool;
- Place a bowl with a small edge close to the pump to collect any spillage. Remove the emergency emptying cap from the filter cover. The water should drain by gravity into the bowl. When the bowl is full, put the cap back on filter cover. Empty the bowl. Repeat the procedure until water stops flowing out;
- Clean the pump if necessary as previously described;
- Replace the filter into the pump and screw it firmly as previously described;
- Replace the emergency emptying cap into the filter cover and close the pump door.

# Something not working

If the washing machine is not working correctly, please carry out the following checks before contacting your local Service Force agent.

**IMPORTANT:** if you call out an engineer to a fault listed below, or to repair a fault caused by incorrect use or installation, a charge will be made even if the appliance is under guarantee.

During machine operation it is possible that the buzzer sounds, the red light of the **Start/Pause** button flashes and one of the following alarm codes appears on the display:

- **E10** : problem with the water supply
- **E20** : problem with water draining
- **E40** : door open
- **EFO** : anti-flooding system has activated

Once the problem has been eliminated, press the **Start/Pause** button to restart the programme. If after all checks, the problem persists, contact your local Service Force Centre.

Symptom	Possible causes
The machine does not start	<ul style="list-style-type: none"> <li>• The door has not been closed. (<b>E40</b>)</li> <li>• The plug is not properly inserted in the power socket.</li> <li>• There is no supply at the socket.</li> <li>• The main fuse or the fuse in the plug has blown.</li> <li>• The <b>Start/Pause</b> button has not been pressed.</li> <li>• The <b>Delay start</b> option has been selected.</li> <li>• The <b>Child Lock</b> function has been enabled.</li> </ul>
The machine does not fill	<ul style="list-style-type: none"> <li>• The water tap is closed. (<b>E10</b>)</li> <li>• The filter in the inlet hose is blocked. (<b>E10</b>)</li> <li>• The inlet hose may be squashed or kinked. (<b>E10</b>)</li> <li>• The door has not been closed. (<b>E40</b>)</li> </ul>
The machine fills then empties immediately	<ul style="list-style-type: none"> <li>• The end of the drain hose is too low.</li> <li>• The end of the drain hose is submerged in water.</li> <li>• There is no vent in the end of the drain hose.</li> </ul>
The machine does not empty and/or does not spin	<ul style="list-style-type: none"> <li>• The drain hose may be squashed or kinked. (<b>E20</b>)</li> <li>• The drain filter may be blocked. (<b>E20</b>)</li> <li>• The <b>Rinse hold</b> option has been selected.</li> <li>• The drainage system pipes are blocked (<b>E20</b>).</li> <li>• The wash load is unbalanced: redistribute the clothes inside the drum to allow the machine to spin.</li> </ul>
There is water on the floor	<ul style="list-style-type: none"> <li>• Too much detergent or unsuitable detergent has been used (creates too much foam).</li> <li>• Check whether there are any leaks from the inlet hose fittings. It is not always easy to see this as the water runs down the hose; check to see if it is damp.</li> <li>• The drain hose may be damaged or not securely positioned.</li> <li>• The filter has not been fully screwed in after cleaning or the emergency emptying cap has not been refitted on the filter.</li> </ul>
Unsatisfactory washing results	<ul style="list-style-type: none"> <li>• Too little detergent or unsuitable detergent has been used. An insufficient amount of detergent leaves the laundry looking grey and causes lime scale to form.</li> <li>• Stubborn stains have not been treated prior to washing</li> <li>• The correct wash programme/temperature has not been selected.</li> <li>• Too much laundry has been placed in the drum.</li> </ul>

Symptom	Possible causes
<b>The machine vibrates when spinning</b>	<ul style="list-style-type: none"> <li>• The internal packing has not been removed.</li> <li>• The machine is in contact with the wall or furniture.</li> <li>• The machine is not level and stable (check diagonally).</li> <li>• The washing load is badly distributed in the drum.</li> <li>• Maybe there is very little laundry in the drum.</li> </ul>
<b>The door will not open</b>	<ul style="list-style-type: none"> <li>• The water level is above the bottom edge of the door.</li> <li>• The machine is heating the water.</li> <li>• The drum is turning.</li> </ul> <p><b>In any case the door can be opened only when the «Door lock» light has gone out.</b></p>
<b>Spinning starts late or the machine does not spin</b>	<ul style="list-style-type: none"> <li>• The electronic balance control device has cut in because the laundry is not evenly distributed in the drum. The laundry is redistributed by reverse rotation of the drum. This may happen several times before the unbalance disappears and normal spinning can resume. If, after few minutes, the laundry is still not evenly distributed in the drum, the machine will not spin. In this case, redistribute the load manually and select the spin programme.</li> </ul>
<b>The machine makes an unusual noise</b>	<ul style="list-style-type: none"> <li>• The machine is fitted with a type of motor which makes a different noise compared with other traditional motors. This new motor ensures a softer start and more even distribution of the laundry in the drum when spinning, as well as increased stability of the machine.</li> </ul>
<b>No water is visible in the drum</b>	<ul style="list-style-type: none"> <li>• Machines based on modern technology operate very economically using very little water without affecting performance.</li> </ul>
<b>The machine does not dry or does not dry properly</b>	<ul style="list-style-type: none"> <li>• The drying time or degree of drying has not been selected</li> <li>• The water tap is not turned on (<b>E10</b>)</li> <li>• The drain filter is clogged (<b>E20</b>)</li> <li>• The machine is overloaded</li> <li>• The selected drying time or dryness degree was not suitable for the laundry.</li> </ul>
<b>The display shows the alarm code <i>EFO</i>:</b>	<ul style="list-style-type: none"> <li>• The anti-flooding system has activated. Disconnect the appliance and contact the Service Force Centre</li> </ul>

# Repairs - After sales service

In the event of your appliance requiring service, or if you wish to purchase spare parts, please contact our extended warranty administrators by telephoning:

**0870 01 07887**

They will give you details for your local Service Force Centre.

Service Force are the appointed national appliance repair agents responsible for warranty repairs to this appliance.

Before calling out an engineer, please ensure you have read the details under the heading "Something Not Working".

When you contact the Service Force Centre you will need to give the following details:

1. Your name, address and post code
2. Your telephone number
3. Clear and concise details of fault
4. The purchase date and found on your receipt.
5. The model and serial number of the appliance (found on the rating plate - see picture)  
So that you always have these numbers to hand, we recommend you to make a note of them here.

Model.....

PNC.....

SN.....

**Your washing machine is covered by a 3 year parts and labour guarantee (see separate details given at point of sale). Please retain your purchase receipt safely for the service engineer to verify the purchase details.**

## Spare parts

An authorised service engineer should service this product, and only genuine spare parts should be used.

Under no circumstances should you attempt to repair the machine yourself. Repairs carried out by inexperienced persons may cause injury or serious malfunctioning. Contact your local Service Force Centre.

